




Intellego
Curing



A Balancing Act

Navigating the Challenges of UV
Curing in Modern Applications

Intellego
Technologies

www.intellego-technologies.com



Table of Contents

| | |
|-----------------------------------------------|---------|
| Exec Summary | 3 |
| Introduction | 4 |
| Problem Statement | 5 |
| Basics of UV Curing | 6 |
| Applications Across Industries | 7 |
| Importance of Optimal Curing | 8 |
| Validation of UV Curing Process | 9 - 11 |
| Limitations in the UV Industry | 12 - 13 |
| Industry Standards and Regulations | 14 |
| Importance of Validation | 15 |
| Dosimeters in UV Curing | 16 |
| Key Features of Intellego Dosimeters | 17 |
| Benefits of Intellego Dosimeters | 18 |
| Preventing Under-Curing & the Risks | 19 |
| Mitigating the Risks with Realtime Monitoring | 20 |
| Dosimeter Feedback Integration | 21 |
| Vulnerabilities of Intellego Dosimeters | 22 |
| Best Practices | 24-26 |
| Future Trends in UV Curing Technology | 27 |
| How to Get Started | 28 |
| References | 29 |

Executive Summary

Integrating Ultraviolet (UV) curing technology into industrial settings presents a transformative solution that enhances production processes. Renowned for its efficiency, eco-friendliness, and potential to reshape the manufacturing landscape, UV curing stands at the forefront of innovative manufacturing solutions. However, a significant challenge within the UV curing landscape is the lack of standardized and cost-efficient validation procedures, leading to inconsistencies and uncertainties regarding the technology's effectiveness and value.

This gap risks manufacturing facilities, impacting product quality and operational efficiency. A robust validation process is imperative to address this validation challenge and ensure the reliability of UV curing practices.

Intellego dosimeters emerge as crucial tools in validating UV curing processes in this context. These dosimeters provide real-time UV intensity and exposure data, empowering precise control over curing. Leveraging dosimeter data, manufacturing facilities can optimize UV curing protocols, ensuring consistent quality and operational excellence.

Dosimeters boast features such as real-time monitoring, personalized data, accuracy, ease of use, and data management, making them indispensable for ensuring the efficacy of UV curing processes.

Recommendations include:

- Incorporating Intellego dosimeters into every UV curing cycle.
- Avoiding dosimeter reuse.
- Maintaining the integrity of dosimeter cards.
- Validating new UV curing equipment for optimal performance.

Timely dosimeter readings, within the immediate aftermath of the curing cycle, are critical for accurate validation. Integrating dosimeter data into UV curing protocols enhances the quality of cured products and ensures compliance with industry standards.

By incorporating validation through adopting Intellego dosimeters, manufacturing facilities can consistently deliver optimal UV curing results, reduce defects, and enhance their industry standing. These practices contribute to improved product quality, operational efficiency, and long-term financial sustainability, establishing Intellego dosimeters as indispensable tools towards the integrity of UV curing processes.



Introduction

In recent years, the UV curing industry has experienced significant growth, attributed to its numerous advantages, including increased productivity, reduced energy consumption, and enhanced product performance. However, under-curing remains a significant concern. Undercuring refers to the incomplete curing of UV-curable materials, which can result in product failure, compromised quality, and decreased durability. It can be especially problematic in industries such as automotive, aerospace, electronics, and healthcare, where the reliability and performance of UV-cured products are crucial.

Establishing standardized validation procedures for UV technology is essential. Standardized and cost-effective validation procedures is a critical challenge in the UV technology landscape. Proper validation makes ensuring plastering and mitigating the risks associated with under-curing difficult. Standardized validation procedures would provide a framework for manufacturers to test and validate their UV curing processes, ensuring that the cured products meet the necessary quality standards.

This would enhance customer satisfaction and help build a strong brand reputation for companies in the UV curing industry. By validating UV technology, manufacturers can have confidence in the performance and reliability of their products, providing added assurance to their customers.

Consequences

The consequences of under-curing in the UV curing industry can be significant and often far-reaching. Firstly, under-cured products may not achieve the desired mechanical and physical properties, reducing product performance and durability. This can result in product failures, customer dissatisfaction, and potential safety hazards. Secondly, inadequate curing can compromise the integrity of coatings, adhesives, and other UV-cured materials, making them more susceptible to chemical degradation, discolouration, and reduced lifespan.





Problem Statement

Adopting Ultraviolet (UV) curing technology has presented a transformative solution in manufacturing processes, promising heightened efficiency and product quality. However, a significant challenge within the UV curing industry revolves around the need for standardized validation procedures. The lack of a systematic approach to measure and ensure the efficacy of UV curing processes introduces uncertainties, risking sub-optimal curing outcomes and potentially compromising the quality of cured materials.

To address this pivotal gap in the UV curing landscape and enhance the reliability of UV technology, there is a pressing need to delve into the requirements for comprehensive validation. This involves emphasizing the essential role of Intellego dosimeters in validating UV exposure levels and providing actionable recommendations for their seamless integration into UV curing protocols. By establishing robust validation processes and leveraging the capabilities of Intellego dosimeters, the UV curing industry can ensure consistent and reliable curing results, fostering enhanced product quality and operational excellence.

Basics of UV Curing


UV curing is a process that utilizes ultraviolet (UV) light to cure or harden materials such as inks, coatings, adhesives, and resins. This technology has gained widespread popularity due to its numerous advantages over traditional curing methods. UV curing offers fast and efficient curing times, reduced energy consumption, superior adhesion, improved chemical resistance, and enhanced durability.

The basic principle of UV curing involves using UV light to initiate a photochemical reaction in the cured material. This reaction causes the molecules in the material to cross-link and form a strong, durable bond. A UV lamp or LED source typically generates the UV light used in curing.

These lamps emit high-intensity UV radiation, primarily in the UVA and UVB wavelengths, which are most effective for curing.

During the UV curing process, the material to be cured is coated or applied onto a substrate and then exposed to the UV light source. The UV light penetrates the material and triggers the photochemical reaction, leading to rapid curing and hardening. The curing time can vary depending on factors such as the material being cured, the thickness of the coating, and the intensity of the UV light source.

UV curing is widely used in various industries, including printing and packaging, electronics, automotive, aerospace, and medical devices. It allows for high-speed production, improved quality control, and curing various materials. However, to ensure optimal curing and prevent under-curing, it is essential to implement standardized validation procedures and adhere to industry best practices.



Applications Across Industries

UV curing has become integral to various industries, offering numerous applications that enhance production processes and product quality. In the printing industry, UV curing is widely used for ink drying and curing, enabling faster production speeds and improved print quality. It ensures vibrant colours, sharp images, and precise curing of inks on various substrates.

UV curing also benefits the automotive industry, particularly in producing automotive coatings. UV-cured coatings provide excellent durability and scratch and chemical resistance, ensuring long-lasting vehicle protection.



Moreover, the rapid curing process increases production efficiency and reduces energy consumption.

UV curing plays a crucial role in manufacturing printed circuit boards (PCBs) and electronic components in the electronics industry. UV-cured adhesives and coatings enable precise bonding, sealing, and encapsulation, ensuring reliable performance and protection against moisture, dust, and other contaminants. The fast curing process also improves production throughput and reduces the risk of heat damage to sensitive electronic components.

Medical device manufacturers rely on UV curing for various applications, including bonding, sealing, and sterilization. UV-cured adhesives provide strong and durable bonds for medical devices, ensuring patient safety and product reliability. UV disinfection systems sanitize medical instruments and equipment, eliminating harmful bacteria and viruses.

The furniture and woodworking industry also benefits from UV curing technology. UV-cured finishes and coatings offer superior durability, resistance to scratches and stains, and enhanced colour stability. These finishes are environmentally friendly, emitting little to no volatile organic compounds (VOCs) during the curing process. UV curing also enables faster production turnaround times, reducing manufacturing costs.

UV curing has proven to be a versatile and efficient technology across various industries. Its applications range from printing and automotive coatings to electronics manufacturing and medical device production. By implementing UV curing processes, businesses can achieve improved product quality, increased production efficiency, and cost savings while meeting industry standards and customer expectations.



Importance of Optimal Curing


Optimal curing, also known as UV curing, is a crucial technology used in various industries for its ability to rapidly and effectively cure materials using ultraviolet light. The importance of optical curing lies in its numerous advantages, making it an indispensable process in manufacturing and production.

One critical benefit of optical curing is its high-speed production capability. Unlike traditional curing methods that require extended drying or curing times, UV curing achieves rapid curing within seconds.

This significantly reduces production time, increases throughput, and improves overall efficiency. Manufacturers can achieve higher productivity levels and meet customer demands more effectively.

Another significant advantage of optical curing is improved quality control. UV curing ensures consistent and uniform curing of materials, minimizing variations and defects in the final product. Precisely controlling UV light exposure allows manufacturers to achieve desired curing levels, enhancing product performance and durability. This level of control is particularly crucial in industries such as electronics, automotive, and medical devices, where product reliability and safety are paramount.

Optimal curing is vital in ensuring finished products' long-term durability and protection. UV-cured coatings and finishes offer excellent resistance to abrasion, chemicals, and weathering, making them ideal for applications that require robust and long-lasting protection against wear, corrosion, and fading.



Validation of UV Curing Processes

UV curing is a powerful technology that revolutionizes industries by rapidly curing materials using UV light. It offers benefits like improved quality, efficiency, and cost savings. Inadequate curing can reduce performance, product failures, and safety hazards. Under-curing compromises coatings and materials, reducing their lifespan.

It also affects UV disinfection efficiency, risking contamination. Understanding UV curing basics, applications, optical curing, and process factors is crucial for optimal results and product durability. Factors like surface prep, equipment calibration, and transparency influence curing, while ideal conditions ensure consistent results.

UV Light Intensity:

UV light intensity is a critical factor in UV curing as it directly influences the speed and effectiveness of the curing process. High intensity ensures rapid curing, a crucial aspect in industries with high-volume production. Conversely, low intensity may lead to incomplete curing, affecting the quality and durability of the cured material. Manufacturers must carefully calibrate UV light sources to achieve specific application intensity levels.

UV Light Spectrum:

Different materials have distinct absorption characteristics, requiring specific wavelengths of UV light for optimal curing. Understanding the material's UV sensitivity is vital to matching the UV light spectrum to its requirements. This ensures that the energy from the UV light is effectively absorbed, initiating the curing reactions. Careful consideration of the UV light spectrum contributes to achieving consistent and reliable curing results across various materials.

Exposure Time:

The duration of UV exposure significantly impacts the curing process. Inadequate exposure time can lead to under-curing, reducing material strength and durability. On the other hand, excessive exposure may cause overheating and damage. Precise control over exposure time is crucial for achieving uniform curing across the material and preventing issues such as tackiness or incomplete curing.



Distance from UV Source:

The distance between the UV source and the material being cured directly affects the intensity of UV light reaching the surface. Proper positioning is essential to ensure uniform curing, preventing variations in curing quality. Manufacturers must consider factors like the geometry of the curing area and the design of the UV curing system to optimize the distance for consistent and efficient curing.

Material Thickness:

The thickness of the material impacts the penetration of UV light. Thicker materials may require longer exposure times or higher-intensity UV light to ensure complete curing throughout the entire thickness. Understanding the material thickness is crucial for selecting appropriate curing parameters and preventing issues like insufficient curing in deeper layers.

Material Composition:

The composition of materials plays a pivotal role in their responsiveness to UV curing. Some materials may inherently lack sensitivity to UV light, necessitating the incorporation of additives or sensitizers to enhance their curing properties. Manufacturers must carefully evaluate the compatibility of materials with UV curing processes and make necessary adjustments to achieve optimal results.

Environmental Conditions:

The curing environment, including temperature, humidity, and air circulation, can impact the curing process. Maintaining ideal conditions helps ensure consistent curing results. Deviations in environmental parameters can lead to variations in curing speed and quality, making it essential for manufacturers to control and monitor these conditions during the curing process.



- Surface Preparation:


Proper surface preparation is crucial for successful UV curing. Contaminants, moisture, or uneven surfaces can interfere with curing, leading to defects such as poor adhesion or incomplete curing. Thorough cleaning, pre-treatment, and surface conditioning provide a conducive environment for adequate UV curing.

- Equipment Calibration:

Regular calibration of UV curing equipment is essential to maintain accurate UV light intensity and exposure settings. Adequately calibrated equipment ensures consistency in curing results over time. Deviations in calibration can lead to variations in curing quality, emphasizing the need for routine maintenance and calibration checks.

- Material Transparency:

The transparency of materials influences their ability to transmit UV light. Transparent or translucent materials allow UV light to reach underlying layers, facilitating the curing of multiple layers. In contrast, opaque materials may require additional curing steps or alternative methods to ensure complete curing. Manufacturers must consider material transparency when designing curing processes to achieve desired results for different material types.





Limitations in the UV industry

In addition to the need for standardised validation procedures, the UV curing industry faces several other issues:

Lack of awareness:

The lack of awareness about UV curing technology poses a significant hurdle to its widespread adoption across various industries. UV curing offers rapid curing times, increased productivity, and enhanced product quality. To address this issue, industry stakeholders must engage in comprehensive outreach programs, educational initiatives, and marketing efforts. These initiatives should highlight successful case studies, demonstrate the versatility of UV curing in different applications, and showcase the long-term cost benefits to encourage more industries to explore and embrace this technology.

Cost:

The cost of UV curing equipment and materials is often cited as a barrier to entry for businesses considering the technology. Initial investments can be higher than traditional curing methods, impacting decision-making. Efforts to address this challenge involve ongoing research and development to optimize manufacturing processes, reduce production costs, and enhance the efficiency of UV curing systems. Industry players should also explore partnerships, bulk purchasing, and financing options to make UV curing more economically viable for a broader range of businesses.

Safety concerns:

UV radiation poses potential health risks to workers if not handled properly. Ensuring the safety of personnel requires the implementation of stringent safety protocols, including the use of appropriate personal protective equipment (PPE) and the establishment of controlled working environments. Training programs should be comprehensive, covering the potential risks of UV radiation exposure and detailing the correct handling procedures. Employers must prioritize the health and safety of their workforce by fostering a culture of awareness and adherence to safety guidelines.

Material compatibility:

While UV curing is versatile, not all materials respond effectively to UV radiation. Some substrates may require additional treatments or may be incompatible with UV curing. Overcoming this challenge involves ongoing research and development efforts to formulate UV-curable materials suitable for a broader range of substrates. Additionally, manufacturers can explore pre-treatment methods and process optimizations to improve the compatibility of UV curing with various materials, expanding its applicability in different industries.



Energy consumption:


The energy consumption associated with UV curing systems, especially in high-volume production environments, raises concerns about operational costs and environmental impact. Addressing this challenge requires developing and adopting more energy-efficient UV curing technologies, such as transitioning to LED UV curing systems. Process optimization, energy recovery systems, and integrating smart technologies to minimize energy usage during idle times can contribute to sustainability and cost-effectiveness in UV curing processes.

Process control and quality assurance:

Maintaining consistent and reliable curing results across different production batches is critical to UV curing. Industries must implement robust process control measures to address this challenge, leveraging advanced monitoring systems and sensors. Real-time feedback mechanisms allow for adjustments during production, ensuring adherence to quality standards. Additionally, comprehensive quality assurance protocols, including regular testing and inspection procedures, are essential to identify and rectify any deviations in the curing process, minimizing defects and ensuring the overall quality of cured products.

Regulatory compliance:

UV curing materials and processes are subject to specific regulations and standards that vary across industries and applications. Staying compliant with these regulations is complex and time-consuming. Industry players must invest in continuous monitoring of regulatory changes, maintain accurate documentation of processes and materials, and establish effective communication channels with regulatory bodies. Adherence to industry-specific standards and proactive engagement in regulatory discussions can help businesses navigate the complex compliance landscape, ensuring the legality and safety of UV curing processes in various applications.





Industry Standards and Regulations

Industry standards and regulations play a crucial role in the UV curing industry, particularly when validating the UV curing process. UV curing validation is a process that ensures that the curing process is consistent, reliable, and effective.

It involves verifying that the UV light source delivers the optimal power and the appropriate exposure time and that the curing process is uniform throughout the product. The validation process ensures product quality, performance, and safety.

Several industry standards and regulations guide and govern the UV curing validation process. These standards cover equipment design, worker safety, and environmental protection. Adhering to these guidelines promotes sustainable and responsible manufacturing practices, contributing to a greener and more eco-conscious industry.

Some essential standards and regulations that apply to UV curing validation include ANSI/ISEA 201-2019, which provides guidelines for testing and validating UV protection on personal protective equipment, and ASTM D904-16, which outlines the standard practices for validating UV curing equipment.

Performing regular UV curing validation is essential to ensure the effectiveness of the UV curing process and maintain compliance with industry standards and regulations. This process involves validating the curing process for each product type and verifying that the curing conditions suit the product's specific requirements. UV curing validation can be performed using various methods, including radiometry, spectrometry, visual inspection and Intellego's patented dosimeters.

By adhering to industry standards and regulations and performing regular UV curing validation, manufacturers can achieve optimal results, enhance product durability, and maintain the highest levels of safety for workers, consumers, and the environment.

Importance of Validation

Validation is a cornerstone in the UV curing industry and is pivotal in ensuring the reliability and consistency of curing processes. The industry's diverse applications, from electronics and automotive to healthcare and packaging, demand stringent quality standards. Validation processes systematically confirm that UV curing systems operate within specified parameters and deliver the intended results.

Manufacturers can establish and maintain control over crucial variables, such as UV light intensity, exposure time, and environmental conditions, by validating UV curing processes. This not only safeguards the quality of the cured products but also aligns with regulatory requirements and industry standards, ensuring compliance and traceability.

Moreover, validation is instrumental in preventing under-curing or overcuring, which can harm cured materials' performance and durability. Undercuring may result in insufficient material strength and adhesion, leading to product failures, while overcuring can cause brittleness and other undesirable characteristics.

Through comprehensive validation protocols, manufacturers can identify and rectify potential issues before they impact production, reducing the risk of defects and waste. The emphasis on validation in the UV curing industry reflects a commitment to delivering products that meet or exceed quality expectations, fostering customer satisfaction, and bolstering the reputation of both individual manufacturers and the industry.




Dosimeters in UV Curing

Intellego's dosimeters are purpose-built to empower data-driven UV curing solutions. These dosimeters are vital in the UV curing industry by ensuring accurate UV exposure levels. Specifically designed for UV curing applications, Intellego dosimeters contribute to the optimization of curing processes, preventing undercuring or overcuring that could compromise the quality of cured materials.

Our dosimeters provide real-time data on UV light intensity and exposure duration in the UV curing sector, where accuracy and reliability are paramount. This functionality enables businesses to validate and maintain optimal curing conditions, enhancing the efficiency of UV curing protocols.

Intellego dosimeters are particularly significant in industries such as electronics and manufacturing, where the quality of cured products directly impacts performance and reliability. Our dosimeters empower businesses to fine-tune their UV curing strategies by offering detailed insights into UV light parameters, ensuring adherence to industry standards and regulatory requirements.

The dosimeter solution is committed to excellence in UV curing, providing manufacturers with the tools to validate and optimize their processes for consistent, high-quality results.



Key Features of Intellego Dosimeters:

Affordability and Cost-Effectiveness:

Intellego dosimeters offer an affordable solution for UV curing processes. This cost-effectiveness makes dosimeters accessible to a broad spectrum of businesses and underscores the economic viability of adopting UV curing technologies.

Flexible Shape and Adaptability:

The flexibility in shape ensures that Intellego dosimeters are adaptable to various surfaces and configurations within UV curing processes. This feature allows dosimeters to conform seamlessly to the contours of different materials, ensuring accurate readings regardless of the shape of the curing area.

Thin Profile and Unobtrusiveness:

At a mere 0.1mm thickness, Intellego dosimeters are exceptionally thin, maintaining an unobtrusive presence during the UV curing process. This thin profile ensures that dosimeters do not interfere with the curing of materials, preserving the integrity of the production cycle.

Integrated User-Friendly App:

Accompanied by a user-friendly app, Intellego dosimeters enhance the monitoring and management of UV curing processes. The app provides a platform for real-time data visualization, dosimeter customization, and comprehensive analytics. This integration allows users to track and analyze UV exposure parameters effortlessly, further optimizing the curing process.

Customization and Tailoring to Specific Needs:

Intellego dosimeters offer customization options, allowing manufacturers to tailor dosimeter parameters or incorporate branding elements. This flexibility ensures that dosimeters can be adapted to meet the unique requirements of different UV curing applications, fostering versatility in manufacturing processes.

User-Friendly Features for Seamless Integration:

Designed with user-friendly features, Intellego dosimeters are easy for operators and technicians to train to use. The simplicity of dosimeter operation ensures a quick learning curve, facilitating efficient integration into UV curing processes and minimizing the need for extensive training sessions.

Benefits of Intellego Dosimeters in UV Curing:

Enhanced Quality Assurance:

The real-time data and validation capabilities provided by Intellego dosimeters offer a robust foundation for enhanced quality assurance in UV curing processes. By continuously monitoring UV light intensity and exposure duration, manufacturers can ensure that curing conditions consistently align with industry standards.

This leads to producing high-quality cured products with reliable performance characteristics, ultimately fostering customer satisfaction and loyalty.

Optimized Curing Processes:

Intellego dosimeters empower businesses to optimize their UV curing protocols through detailed insights into UV light parameters. The ability to fine-tune curing conditions based on real-time data enhances overall operational efficiency. This optimization reduces production cycle times, increases throughput, and improves resource utilization. The streamlined curing processes contribute to a more agile and responsive manufacturing environment.

Risk Mitigation:

Dosimeters are pivotal as proactive tools in risk mitigation during UV curing. By validating UV exposure levels, dosimeters act as an early warning system against under-curing or over-curing, minimizing the risk of material defects. This preventative approach ensures the reliability and durability of cured products, mitigating potential downstream issues that could arise from compromised curing conditions.

Compliance with Industry Standards:

Intellego dosimeters assist businesses in adhering to stringent industry regulations and standards governing UV curing processes. Compliance with these standards is crucial for industries with high-quality and safety requirements, ensuring that manufacturers consistently meet or exceed the set benchmarks.

This establishes credibility and mitigates legal and reputational risks associated with non-compliance.

Cost Savings and Waste Reduction:

Precise monitoring and validation provided by dosimeters contribute to significant cost savings in the UV curing. By avoiding undercuring or overcuring, manufacturers reduce material waste and energy consumption. The optimized curing conditions promoted by dosimeters lead to more efficient resource utilization, resulting in direct cost savings. Additionally, reducing material waste aligns with sustainable manufacturing practices, promoting environmental responsibility and long-term cost-effectiveness.

Preventing Undercuring & The Risks

Undercuring in the UV industry poses significant risks to cured materials' quality, functionality, and durability. When materials receive the necessary exposure to UV light for the required duration, the curing process still needs to be completed. This can lead to various issues, including diminished mechanical strength, reduced adhesion, and compromised chemical resistance.

Undercured materials may exhibit surface defects, such as tackiness or an uneven finish, affecting the final product's aesthetic appeal and overall performance. In industries where precision is paramount, such as electronics and medical devices, under-curing introduces a heightened risk of product malfunction or failure, potentially compromising the safety and reliability of critical components.

Beyond the immediate impact on product quality, under-curing can also have financial implications for manufacturers. Products not meeting desired specifications may need to be scrapped or reworked, leading to increased production costs and extended cycle times. Furthermore, under-curing can result in increased post-curing times or the need for additional curing steps, affecting overall operational efficiency.

To mitigate these risks, businesses in the UV industry must implement robust validation processes, utilize dosimeters for real-time monitoring, and establish comprehensive quality control measures. These proactive measures ensure that the curing process meets the required standards, preventing the detrimental consequences of under-curing.



Mitigating These Risk With Real-time Monitoring

Real-time monitoring with Intellego dosimeters revolutionizes the landscape of UV curing processes, providing manufacturers unparalleled control and visibility into their operations. Intellego dosimeters offer instant, accurate feedback on UV light intensity and exposure duration during curing. This real-time monitoring capability empowers operators and technicians to make immediate adjustments, ensuring UV exposure levels align precisely with the specific application's requirements.

By continuously assessing UV parameters, Intellego dosimeters enable businesses to proactively identify and address potential issues related to undercuring or overcuring, thereby maintaining optimal curing conditions.

The user-friendly interface of Intellego dosimeters enhances the monitoring experience, allowing operators to interpret data and make informed decisions quickly. The dosimeters display crucial information in a clear and accessible format, facilitating quick responses to deviations from desired curing parameters.

This real-time monitoring capability is precious in dynamic production environments where variables may change, ensuring that curing conditions remain consistent and that the quality of cured materials is upheld.

Additionally, the data-driven insights provided by Intellego dosimeters empower businesses to conduct thorough analyses of their UV curing processes, facilitating continuous improvement and fine-tuning protocols for maximum efficiency and quality assurance. Real-time monitoring with Intellego dosimeters is a transformative tool that safeguards against curing issues and optimizes UV curing processes for enhanced productivity and exceptional final product quality.



Dosimeter Feedback Integration

Integrating dosimeter feedback into the UV curing industry, particularly with Intellego dosimeters designed as versatile cards, introduces a new dimension of simplicity and effectiveness in monitoring and optimizing curing processes. As these dosimeter cards traverse the UV curing system and the products being cured, they capture a comprehensive record of UV light exposure.

This dosimeter feedback serves as a tangible, real-world indicator of the exact dosage received by the materials throughout the curing cycle. The dosimeter cards are equipped with innovative & *patented* color-changing ink that visually represents the UV dosage, allowing operators to quickly and easily assess the adequacy of the curing process.

Integrating dosimeter feedback into UV curing operations enhances quality control and process management. Operators can visually inspect the dosimeter cards at any point in the production line, gaining immediate insights into the uniformity of UV exposure across materials. Deviations in color patterns indicate potential undercuring or overcuring, prompting timely adjustments to the UV curing system.

This hands-on feedback system offers a tangible and straightforward approach to quality assurance, allowing operators to validate the efficacy of the UV curing process without the need for complex and expensive equipment or extensive training. As dosimeter cards seamlessly become a part of the production workflow, dosimeter feedback integration with Intellego dosimeters ensures a practical and efficient means of achieving and maintaining optimal UV curing conditions throughout the manufacturing process.



Vulnerabilities Of Intellego Dosimeter Cards:



Single-Use:

Dosimeter cards, designed for single use, have advantages and drawbacks. On the positive side, they offer a straightforward and disposable solution for monitoring radiation exposure during specific periods. However, the single-use nature introduces recurring costs, as each monitoring session necessitates a new dosimeter card. This financial consideration becomes particularly relevant for industries requiring continuous or frequent monitoring. Additionally, the disposal of used dosimeter cards raises environmental concerns, prompting the need for responsible waste management practices to mitigate the ecological impact.

Lack of Real-Time Monitoring:

The absence of real-time monitoring capabilities in dosimeter cards poses challenges in environments where immediate response to changes in radiation levels is crucial. Dosimeter cards can only provide data after the exposure period, limiting the ability to respond promptly to sudden spikes or unexpected alterations in radiation levels. This limitation is especially notable in dynamic work environments where radiation levels can fluctuate rapidly, emphasizing the importance of supplementary real-time monitoring solutions to ensure a timely and effective response to potential hazards.

Vulnerability to Damage:


Dosimeter cards are more susceptible to physical damage than alternative dosimeter types. Their vulnerability to bending, tearing, or exposure to adverse environmental conditions raises concerns about the accuracy and reliability of the data they provide. To mitigate this vulnerability, users must exercise caution in handling dosimeter cards, and organizations may need to implement additional protective measures. Regular calibration checks and proper storage conditions are essential to preserving the integrity of dosimeter cards and ensuring their accuracy over time.

Data Interpretation:

Dosimeter cards require users to take readings promptly. In instances where readings are not taken within a narrow timeframe, typically 15 minutes after the item or individual has been exposed, the accuracy of the data can be compromised. This time-sensitive nature emphasizes the need for timely and attentive responses from users. Failure to take readings within the specified timeframe can result in skewed data, potentially leading to inaccuracies in assessing radiation exposure levels. Therefore, training programs and clear operational procedures become crucial to ensure that users are knowledgeable about dosimetry principles and diligent in the prompt collection of data for accurate interpretation.

Limited Compatibility:

Dosimeter cards may encounter challenges in terms of compatibility with broader UV monitoring or data management systems. The lack of seamless integration can result in data silos, where dosimeter card data exists independently from other relevant information. Overcoming compatibility issues may require additional steps in the data analysis process or investment in customization efforts to ensure smooth data exchange between dosimeter cards and other monitoring systems. Organizations aiming for a comprehensive and streamlined UV infrastructure should carefully evaluate the compatibility of dosimeter cards with existing systems and consider the potential need for interface development or protocol adjustments.



Best Practices:

Task: Take dosimeter readings promptly, within ten minutes of the curing cycle concluding.

Recommendation: Retrieving dosimeter data within 10 minutes after the cycle ends. This timeframe is chosen deliberately to eliminate the possibility of light contamination, which can potentially skew the results. By retrieving data within this timeframe, curing facilities can rely on the precision of the information captured.

Outcome: By following this practice, the data collected accurately reflects the effectiveness of the disinfection cycle. This prompt data retrieval ensures that product managers and quality services have access to precise, consistent, uniform data that they can use for further analysis and decision-making. It safeguards against potential inaccuracies if data retrieval is delayed, providing manufacturing facilities with the confidence that their curing processes are meticulously recorded and validated.

Task: Dosimeter cards should not be tampered with or defaced.


Recommendation: Dosimeter cards should never be tampered with. Cutting, peeling, or otherwise altering them can result in false readings and inaccurate disinfection data.

Outcome: Ensuring that dosimeter cards remain untouched guarantees the accuracy of the readings. Any tampering with the dosimeter card, even if unintentional, may compromise the integrity of the reactive ink. Consistently handling dosimeter cards with care and refraining from any form of alteration ensures the reliability of the data collected during the curing process.

Task: Don't reuse dosimeter cards; they are single-use items.

Recommendation: Dosimeter cards are designed for single use only. After completing a curing cycle, retrieve the dosimeters from the designated surface, visually validate the dosimeter's UV exposure, record results, and dispose of them. Attempting to reuse dosimeter cards is not advisable because the reaction that occurs when exposed to UV light cannot be replicated.

Outcome: Adhering to this guideline eliminates the possibility of false readings being recorded and records of the exposure levels being recorded. Dosimeter cards are specifically engineered to react to UV exposure accurately just once. Reusing them could lead to inaccurate data, undermining the integrity of the curing monitoring process. Recycling dosimeter cards after each use means production facilities can maintain the highest standard of data accuracy.



Task: Every time you change the settings (e.g., the intensity of the lamp or the speed of the conveyor belt), use the allocated dosimeter cards to validate the process.

Recommendation: It is crucial to validate the curing process with dosimeter cards each time there is a change in settings, such as adjusting the lamp's intensity or the conveyor belt's speed. This practice ensures that the impact of setting changes on UV exposure is accurately measured and documented. Employing dosimeter cards immediately after adjustments helps maintain a reliable record of the disinfection process under varying conditions.

Outcome: By adhering to this recommendation, manufacturing facilities can confidently assess the effectiveness of different curing configurations. This proactive approach allows for collecting precise data on how changes in settings influence UV exposure, contributing to a comprehensive understanding of the curing process. Regular validation using dosimeter cards in response to setting adjustments ensures that the disinfection parameters are consistently optimized for maximum efficacy.

Task: Validate your curing cycle twice daily, once in the morning and once in the evening.

Recommendation: To uphold the reliability of the curing cycle, it is advised to validate the process twice daily – once in the morning and once in the evening. This routine verification ensures that the curing equipment consistently operates efficiently throughout the day. Any potential deviations from the optimal curing conditions can be promptly identified and addressed by conducting validations at regular intervals.

Outcome: Implementing this validation schedule establishes a robust monitoring system for the curing cycle. Regular checks in the morning and evening offer a comprehensive overview of the equipment's performance over different periods, enabling quick corrective actions if needed. This consistent validation protocol ensures that the disinfection process remains effective and follows established standards, minimizing the risk of variations that may compromise product quality.

Task: Accurately spread the dosimeters across your conveyor system to ensure all data is recorded.

Recommendation: Proper placement of dosimeters on the conveyor belt is crucial to capture comprehensive data during the curing process. Dosimeters should be accurately spread across the entire width of the belt to ensure uniform UV exposure. This practice guarantees that data collected reflects the performance of the entire curing area, preventing potential discrepancies that may arise if dosimeters are concentrated in specific areas.

Outcome: Following this recommendation ensures that the dosimeters capture representative data from all conveyor belt parts. Accurate placement guarantees a thorough assessment of UV exposure levels, contributing to the overall reliability of the disinfection process monitoring. By preventing localized variations in UV exposure, manufacturing facilities can have confidence in the consistency and effectiveness of their curing cycles.

Task: Check recommendations based on industry; each lamp and curing device varies.

Recommendation: It is important to know that the recommendations for dosimeter usage may vary based on industry standards and the specific characteristics of each lamp and curing device. Before implementing dosimeter protocols, carefully review and align them with industry best practices and unique equipment specifications. This diligence ensures that dosimeter usage is tailored to the specific requirements of the curing device, guaranteeing accurate and meaningful data collection.

Outcome: Manufacturing facilities can optimise their monitoring processes by checking and aligning dosimeter recommendations with industry standards and device specifications. Adhering to industry-specific guidelines prevents potential discrepancies and enhances the overall reliability of the collected data. This approach ensures that dosimeter usage is tailored to the nuances of each curing device, providing a more accurate representation of the disinfection process that is in line with industry expectations.





Future Trends in UV Curing Technology

The future of UV curing technology promises to be marked by innovative advancements that enhance efficiency, versatility, and sustainability across various industries. One prominent trend on the horizon is the continued development of LED-based UV curing systems. LED technology offers a more energy-efficient and environmentally friendly alternative to traditional mercury vapor lamps as it advances.

LED UV curing reduces energy consumption and provides instant on/off capabilities, contributing to further operational efficiency. This trend aligns with the growing emphasis on sustainable manufacturing practices and addresses concerns about the environmental impact of UV curing processes.

Another notable future trend involves the integration of innovative technologies and data analytics into UV curing systems. Manufacturers are exploring incorporating artificial intelligence and machine learning algorithms to optimize curing processes based on real-time data from dosimeters and other monitoring devices. This data-driven approach enables predictive maintenance, early detection of potential curing issues, and adaptive control of UV exposure parameters.

The result is a more proactive and responsive UV curing environment, minimizing risks associated with undercuring or overcuring while maximizing the efficiency of production processes.

Furthermore, advancements in materials and formulations compatible with UV curing are anticipated. Researchers are focusing on developing UV-curable materials with enhanced properties, such as increased flexibility, durability, and resistance to environmental factors. These new formulations open doors to novel applications in electronics and healthcare industries.

Additionally, exploring 3D printing technologies with UV curing is gaining momentum, offering the potential for intricate, high-resolution 3D-printed objects with rapid curing times. The synergy between evolving UV curing technologies and complementary innovations is poised to redefine manufacturing standards and capabilities, paving the way for a future where precision, speed, and sustainability converge in UV curing processes.



How to get started

Getting started with Intellego's UV dosimeter is simple and seamless.

- **Explore Our Products:** Browse our range of data-driven dosimeters. Discover the right dosimeter that fits your specific needs and application. If you are unsure about exactly what dosimeter can help your industry, don't hesitate to get in touch with us [here](#), and our sales team will be on hand to assist you on your journey.
- **Request a Quote:** Fill out a quick form or contact our dedicated sales team to request a personalized quote tailored to your requirements. We are here to assist you in finding the perfect dosimeter solution for your organization.
- **You can place your order through your Advisor:** Once you receive your quote and are ready to move forward, you can contact your dedicated sales representative to place your order safely. Our team will ensure a smooth purchasing experience.
- **Experience Seamless Integration:** Upon receiving your dosimeters, our team will provide guidance and support for seamless integration into your existing UV curing processes, allowing you to maximize the benefits of our dosimeters and enhance your curing.
- **Continued Support:** Our expert support team is available to answer any questions, offer expert advice, and assist you throughout your experience with our dosimeters, including your next order and any concerns.



References

[1] <https://www.ncbi.nlm.nih.gov/pmc/articles/PMC9160814//>

[2] <https://pubmed.ncbi.nlm.nih.gov/23961739/>

[3] <https://www.dukehealth.org/blog/uv-light-helps-duke-hospitals-fight-transmission-of-superbugs>

[4] <https://www.ncbi.nlm.nih.gov/pmc/articles/PMC9769028/>

[5] <https://www.ncbi.nlm.nih.gov/pmc/articles/PMC9681192/>

[6] <https://www.cdc.gov/policy/polaris/healthtopics/hai/index.html>

[7] <https://www.sciencedirect.com/science/article/pii/S0305417919300920>



Intellego

Curing



+46 735 34 46 34



info@intellego-technologies.com



www.intellego-technologies.com



Intellego Technologies AB
C/O iOffice
Kungsgatan 60
111 22 Stockholm
Sweden